



SuperSense Laser

- Bis zu 200 cm Tankhöhe
- Laserbasierte Messung
- Signalausgabe digital via Bluetooth
- Signalausgabe analog von 0 - 2,5 Volt
- Funktioniert für fast alle Tanks und Tankarten

Typenbezeichnung	Artikelnummer	Hinweis
SuperSense Laser	SS-FLS-2200	Einzelsensor, analoge Signalausgabe
SuperSense Laser Kit	SS-FLS-2200-KIT	Sensor inkl. Montagematerial und Anschlusskabel, analoge Signalausgabe
SuperSense Laser Wireless	SS-FLS-2200LW	Einzelsensor mit integriertem Bluetooth und analoger Signalausgabe
SuperSense Laser Kit Wireless	SS-FLS-2200LW-KIT	Sensor, inkl. Montagematerial und Anschlusskabel. Signalausgabe via integriertem Bluetooth sowie analog

Technische Daten	
Spannungsversorgung	10 - 30 V DC
Leistungsaufnahme	ohne Bluetooth: <0,05 Watt mit Bluetooth <0,1 Watt)
Signalausgang Bluetooth	Zur Verwendung mit der SuperSense App
Signalausgang Analog	Analoges Spannungssignal von 0 - 2,5 Volt
Kalibrierung	Für Tanks von 0 - 200 cm. Kalibrierung erfolgt direkt am Sensor. Zur Kalibrierung ist keine spezielle Software oder Programmieradapter notwendig.

Ansprechpartner für technische Fragen

Stefan Roth
Tel. +498031.22044-65
sro@comworks.de

Josef Stuffer
Tel. +498031.22044-99
jst@comworks.de



SuperSense Laser

- Up to 200 cm tank height
- Laser-based fill level sensor
- Digital signal output via Bluetooth
- Analog signal output from 0 - 2.5 volts
- Works for almost all tanks and tank types

Type designation	Order Number	Hinweis
SuperSense	SS-FLS-2200	Single sensor, analog signal output
SuperSense Kit	SS-FLS-2200-KIT-75	Sensor incl. mounting material and connection cable, analog signal output
SuperSense Wireless	SS-FLS-2200W	Single sensor with integrated Bluetooth and analog signal output
SuperSense Kit Wireless	SS-FLS-2200W-KIT	Sensor, incl. mounting material and connection cable. Signal output via integrated Bluetooth and analog

Technical data	
Power supply	10 - 30 V DC
Power consumption	without Bluetooth: <0,05 Watt with Bluetooth <0,1 Watt)
Bluetooth signal output	For use with the SuperSense App
Analog signal output	Analog voltage signal from 0 - 2.5 volts
Calibration	For tanks from 0 - 75 cm. Calibration takes place directly on the sensor. No special software or programming adapter is required for calibration.

Contact for technical questions

Stefan Roth
Tel. +498031.22044-65
sro@comworks.de

Josef Stuffer
Tel. +498031.22044-99
jst@comworks.de